



## **CROSS-CONNECTION CONTROL PROGRAM**

Dear Utility Customer,

The Potable water supplied to your facility is provided by a water system owned by Village Center Community Development District (VCCDD). VCCDD is responsible for the operation and maintenance of the public water supply beginning at the source and ending at the point of delivery to the customer. A critical element to operating a potable water system is to ensure the protection of the health and safety of the water supplied. One of the ways that this is achieved is by requiring that a Backflow Prevention Assembly be installed at all service connections. A Backflow Prevention Assembly is typically either a Double Check (DC) or Reduced Pressure Assembly (RP) and is located on the customer side of the water meter. Backflow Prevention Assemblies are installed on water service lines to all commercial buildings, irrigation, and fire line services. This is further explained in the Cross-Connection Control Program Handbook that was created by VCCDD in compliance with the rules of the Florida Department of Environmental Protection (FDEP). The Cross-Connection Control Program Handbook outlines the requirements of the customer, which includes installation and annual testing and maintenance on all Backflow Prevention Assemblies. A copy of the Cross-Connection Control Handbook can be downloaded on our website at [www.DistrictGov.org](http://www.DistrictGov.org) by selecting the following: Departments - Utilities - Commercial Customers - and then under the heading Cross-Connection Control Handbook, select VCCDD - Download Here.

### **COMMONLY ASKED QUESTIONS REGARDING CROSS-CONNECTION AND BACKFLOW**

#### ***What is a cross-connection?***

A cross-connection is a point in a plumbing system where the potable water supply is connected to a non-potable source.

#### ***Where might cross-connections be found?***

They can be found in all plumbing systems in areas such as:

- Wash Basins and Service Sinks
- Irrigation sprinkler Systems
- Medical and Dental Equipment
- Hose Bibs
- Photo Developing Equipment
- Fire Sprinkler Systems

#### ***What is backflow?***

It is the unwanted flow of non-potable or contaminated fluids back into the customer's plumbing system and/or the public water system. There are two types of backflow, see below:

- Backsiphonage- caused by a negative pressure in the supply line to a facility or plumbing fixture.
- Backpressure- can occur when the potable water supply is connected to another system operated at a higher pressure or has the ability to create pressure. Primary causes are booster pumps, pressure vessels, elevated plumbing, etc.

#### ***What is a cross-connection control program?***

It is a program required by the FDEP to detect and prevent possible sources of non-potable water or contaminants from entering the public water supply.

#### ***Why do backflow assemblies need to be tested every year?***

The backflow assembly is a mechanical device that needs maintenance just as a vehicle does. The annual test indicates if the internal check valves and mechanics are working properly. Annual testing and maintenance, if necessary, is also required by FDEP and VCCDD.



<b>VCCDD COMMERCIAL CONNECTIONS</b>	
<b>APPROVED BACKFLOW PREVENTION DEVICES</b>	
<b>Connection Type</b>	<b>Approved BFP Device</b>
Restaurant	DCVA
Medical/Dental/Veterinary/Eye Care	RP
Laboratory/Blood Center	RP
Office	DCVA
Grocery Store	RP
Beauty Salon/Spa	RP
Drug Store	DCVA
Pet Store	CDVA
Convenience Stores	DCVA
Banks/Financial	DCVA
Home Improvement/Hardware	RP
Clothing Retail	DCVA
Furniture Retail	DCVA
Restroom Facility	DCVA
Pool	DCVA with Air Gap
Postal Facility	DCVA
School	DCVA
Church	DCVA
Irrigation (Direct Connection/Commercial)	PVB or RP
Irrigation (Internal Connection/Residential)	AVB, PVB, or RP
Fire Protection System (Without Chemical Additives)	DCVA
Fire Protection System (With Chemical Additives)	RP
Funeral Home	RP
Maintenance Facility (Golf, Landscape, etc.)	RP
Wastewater Pumping Station	RP
Wastewater Treatment Plant	RP
Car Wash	RP
Assisted Living/Nursing Facility	RP
<b>Definitions</b>	
BFP	Backflow Prevention
AVB	Atmospheric-type Vacuum Breaker
DCVA	Double Check Valve Assembly
PVB	Pressure Vacuum Breaker
RP	Reduced Pressure Assembly
<b>Notes</b>	
1. Backflow Prevention Devices for facility types not described above shall be submitted to and approved by the District or its authorized representative prior to installation.	
2. An alternate Backflow Prevention Device may be submitted for approval. Alternate devices shall be approved by the District or its authorized representative prior to installation.	